



IPMICFG

User's Guide

Revision 1.8

The information in this USER'S GUIDE has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, makes no commitment to update or to keep current the information in this manual, or to notify any person organization of the updates. Please Note: For the most up-to-date version of this manual, please see our web site at www.supermicro.com.

Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this manual at any time and without notice. This product, including software, if any, and documentation may not, in whole or in part, be copied, photocopied, reproduced, translated or reduced to any medium or machine without prior written consent.

DISCLAIMER OF WARRANTY ON SOFTWARE AND MATERIALS. You expressly acknowledge and agree that use of the Software and Materials is at your sole risk. FURTHERMORE, SUPER MICRO COMPUTER INC. DOES NOT WARRANT OR MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE SOFTWARE OR MATERIALS IN TERMS OF THEIR CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY SUPER MICRO COMPUTER INC. OR SUPER MICRO COMPUTER INC. AUTHORIZED REPRESENTATIVE SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY. SHOULD THE SOFTWARE AND/OR MATERIALS PROVE DEFECTIVE, YOU (AND NOT SUPER MICRO COMPUTER INC. OR A SUPER MICRO COMPUTER INC. AUTHORIZED REPRESENTATIVE) ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICE, REPAIR, OR CORRECTION.

LIMITATION OF LIABILITY. UNDER NO CIRCUMSTANCES INCLUDING NEGLIGENCE, SHALL SUPER MICRO COMPUTER INC. BE LIABLE FOR ANY INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES THAT RESULT FROM THE USE OR INABILITY TO USE THE SOFTWARE OR MATERIALS, EVEN IF SUPER MICRO COMPUTER INC. OR A SUPER MICRO COMPUTER INC. AUTHORIZED REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any disputes arising between manufacturer and customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Super Micro's total liability for all claims will not exceed the price paid for the hardware product.

Manual Revision: 1.8
Release Date: January 21, 2020

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document.

Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2020 by Super Micro Computer, Inc.
All rights reserved.
Printed in the United States of America

Document Revision History

Date	Revision	Description
2020/01/21	1.8	1. Added options to the "-fd" command. 2. Added the "-addrptl" command to set up IP protocol. 3. Added a function to display sets of commands. (This function is not available on DOS.)
2019/07/01	1.7	1. Added the EFI version of IPMICFG. 2. Added the IPv6 routing functions. (option: -ipv6) 3. Supported the UEFI PXE boot options, including -reset and -soft commands. 4. Added the mel (Maintenance Event Log) command set. (option: -mel) 5. Removed the -fru 1m, 1p, 1s, 2m, 2p, 2s, 3s commands. 6. Added the auxiliary firmware revision in "-ver" command.
2018/03/02	1.6	1. Added IPv6 setting functions. 2. Supported BBP2 (BBP + PSU) module. 3. Supported MRC error code for Intel® Xeon® Scalable Processors with Intel® C620 Series Chipsets. 4. Fixed the known issues.
2017/09/01	1.5	1. Modified the NVME remove commands.
2017/06/20	1.4	1. Added the DCMI commands. 2. Removed the -recoverbiosinfo command.
2016/11/23	1.3	1. Modified description of the -fru DMI feature. 2. Modified description of the -pminfo feature. 3. Updated the "Operation Requirements" chapter.
2016/08/23	1.2	1. Added the Get/Set host name command.
2016/01/05	1.1	1. Added the TAS commands. (DOS was NOT supported) 2. Updated the NVME commands. (DOS was NOT supported) 3. Added the summary command.
2015/06/15	1.0	Initial document.

Contents

1	IPMICFG Overview.....	6
1.1	Features	6
1.2	Operation Requirements	7
1.2.1	System Requirements	7
1.2.2	Software Requirements	8
1.2.3	Installing Additional Drivers.....	8
1.3	Typographical Conventions	8
2	Installation and Setup.....	9
2.1	Installing IPMICFG	9
3	Basic User Operations	10
3.1	Setting Up IPMI Addresses.....	11
3.1.1	Examples of Command Executions	12
3.2	IPMI Management Functions.....	16
3.2.1	Examples of Command Executions	18
3.3	Node Management (NM) 2.0 Functions	20
3.3.1	Examples of Command Executions.....	20
3.4	IPMI User & Configuration Management Functions	23
3.4.1	Examples of Command Executions	24
3.5	IPMI Sensor & System Event Management	27
3.5.1	Examples of Command Executions	27
3.6	FRU Management	29
3.6.1	Examples of Command Executions	29
3.7	Multi Node Management	32
3.7.1	Examples of Command Executions.....	32
3.8	TAS Management	34
3.8.1	Examples of Command Executions	34
3.9	NVME Management.....	35
3.9.1	Examples of Command Executions	36
3.10	DCMI Management.....	37
3.10.1	Examples of Command Executions	37
4	Third Party Software.....	39
4.1	IPMI Tool	39

Contacting Supermicro.....	40
----------------------------	----

1 IPMICFG Overview

IPMICFG is a command line tool utility, providing IPMI commands and Supermicro proprietary OEM commands to configure and monitor IPMI devices. It requires no pre-installation and is easy to use for basic IPMI configuration and BMC status reading and monitoring.

1.1 Features

- Setting up IPMI IP addresses
- Setting up IPMI configurations
- Configuring IPMI User Management
- Configuring IPMI FRU
- Managing the System Event Log (SEL)
- Managing IPMI with the node management (NM) protocol

1.2 Operation Requirements

To run basic operations, you must meet the following requirements.

1.2.1 System Requirements

Environment	Requirements
Hardware	Free Disk Space: 200 MB Available RAM: 64 MB Baseboard Management Controller (BMC) must support Intelligent Platform Management Interface (IPMI) version 2.0 specifications.
Operating System	<ul style="list-style-type: none">• DOS 5.0 or later version• Microsoft Windows 7 / 8 / 8.1 / 10 / Server 2003 32bit and 64bit / Server 2008 32bit and 64bit / Server 2012 / Server 2016• Operating system must be pre-installed Microsoft Visual C++ 2008 SP1 Redistributable Package. Download Link: http://www.microsoft.com/en-us/download/details.aspx?id=29• Microsoft Windows 2008 R2 x64 must be pre-installed KB3033929 patch. Download Link: https://www.microsoft.com/en-us/download/details.aspx?id=46083• Microsoft Windows 7 x64 must be pre-installed KB3033929 patch. Download Link: https://www.microsoft.com/en-us/download/details.aspx?id=46148• Linux Kernel version 2.6.x or higher. Ex: Red Hat Enterprise Linux (RHEL) 6.8 and 7.2 SUSE Linux Enterprise Server (SLES) 11 SP4 and 12 SP1 Ubuntu Server 14.04 LTS and 16.04 LTS• UEFI Shell

1.2.2 Software Requirements

Program/Script	Description
\DOS\IPMICFG.exe	IPMICFG DOS (DOS 5.0)
\Linux\32bit\IPMICFG-Linux.x86	IPMICFG Linux 32bit
\Linux\64bit\IPMICFG-Linux.x86_64	IPMICFG Linux 64bit
\Windows\32bit\IPMICFG-Win.exe	IPMICFG Windows 32bit
\Windows\64bit\IPMICFG-Win.exe	IPMICFG Windows 64bit
\UEFI\IPMICFG.efi	IPMICFG UEFI
*.dat files	database for MB type and SEL event table

1.2.3 Installing Additional Drivers

Linux:

The Linux version of IPMICFG will automatically use the built-in Linux IPMI driver from ipmitool to access BMC. If no IPMI driver is available, IPMICFG will use its internal API to access BMC, however the performance will be slow.

To load an IPMI driver, type the following commands to access the IPMI driver:

1. # modprobe ipmi_msghandler
2. # modprobe ipmi_devintf
3. # modprobe ipmi_si

1.3 Typographical Conventions

This manual uses the following typographical conventions.

`Courier-New font size 10` represents command line instructions (in CLI) in terminal mode.

Bold is used for emphasizing keywords.

Italic is used for variables and section titles.

< > enclose the parameters in syntax description.

[ipmicfg_HOME] represents the prompt for inputs in terminal mode.

| A vertical bar separates items in a list.

2 Installation and Setup

2.1 Installing IPMICFG

Get the IPMICFG_x.xx.x_build.xxxxxx.zip installer, and then unzip it in your environment. You will see the directory list:

DOS:

Execute \DOS\IPMICFG.exe

Linux 32bit:

Execute /Linux/32bit/IPMICFG-Linux.x86

Linux 64bit:

Execute /Linux/64bit/IPMICFG-Linux.x86_64

Windows 32bit:

Execute \Windows\32bit\IPMICFG-Win.exe

Windows 64bit:

Execute \Windows\64bit\IPMICFG-Win.exe

UEFI Shell:

Execute \UEFI\IPMICFG.efi

3 Basic User Operations

Usage:

```
[ipmicfg_HOME] > IPMICFG <command> [option/data...]
```



Note: To display sets of commands, use the command `[ipmicfg_HOME] > IPMICFG <command> -help`

Here is an example of displaying the set of `-sdr` commands to illustrate the steps.

Example:

```
[ipmicfg_HOME] > IPMICFG -sdr -help
```

Command: `-sdr`

Command(s) :

<code>-sdr [full]</code>	Show SDR records and reading
<code>-sdr del <sdr id></code>	Delete SDR record
<code>-sdr ver <v1> <v2></code>	Get/Set SDR version (v1, v2 are BCD format)

3.1 Setting Up IPMI Addresses

Options for Using IPMICFG	
-m	Shows IP and MAC.
-m <ip>	Sets IP (format: ###.###.###.###).
-a <mac>	Sets MAC (format: #:#:#:#:#:#:).
-k	Shows Subnet Mask.
-k <mask>	Sets Subnet Mask (format: ###.###.###.###).
-dhcp	Gets the DHCP status.
-dhcp on	Enables the DHCP.
-dhcp off	Disables the DHCP.
-g	Shows a Gateway IP.
-g <gateway>	Sets a Gateway IP (format: ###.###.###.###).
-garp on	Enables the Gratuitous ARP.
-garp off	Disables the Gratuitous ARP.
-ipv6 mode	Shows the IPv6 mode.
-ipv6 mode <mode>	Sets the IPv6 mode.
-ipv6 autoconfig	Shows IPv6 auto configuration.
-ipv6 autoconfig on	Enables IPv6 auto configuration.
-ipv6 autoconfig off	Disables IPv6 auto configuration.
-ipv6 list	Lists IPv6 static addresses.
-ipv6 duid	Show IPv6 DUID.
-ipv6 dns [IPv6 addr]	Gets/Sets IPv6 DNS server.
-ipv6 add <id> <IPv6 addr> <prefix>	Adds IPv6 static address.
-ipv6 remove <id>	Removes IPv6 static address.
-ipv6 route	Displays IPv6 static route.
-ipv6 route on	Enables IPv6 static route.
-ipv6 route off	Disables IPv6 static route.
-ipv6 route list	Lists IPv6 static router information.
-ipv6 route <id> <prefix value> <prefix length> <IPv6 addr>	Sets IPv6 static router information.
-ipv6 route clear <id>	Clears IPv6 static router information.
-addrptl [option]	Gets/Sets IP address protocol

3.1.1 Examples of Command Executions

The following are selected options from the above table to illustrate their execution.

- **Example 1. Showing IP and MAC.**

```
[ipmicfg_HOME] > IPMICFG.exe -m
```

```
IP=192.168.12.34
```

```
MAC=00:25:90:AB:CD:EF
```

- **Example 2. Setting IP.**

```
[ipmicfg_HOME] > IPMICFG.exe -m 192.168.56.78
```

```
IP=192.168.56.78
```

- **Example 3. Getting the DHCP status.**

```
[ipmicfg_HOME] > IPMICFG.exe -dhcp
```

```
DHCP is currently disabled.
```

- **Example 4. Showing Subnet Mask.**

```
[ipmicfg_HOME] > IPMICFG.exe -k
```

```
Subnet Mask=255.255.255.0
```

- **Example 5. Showing a Gateway IP.**

```
[ipmicfg_HOME] > IPMICFG.exe -g
```

```
Gateway=192.168.12.254
```

- **Example 6: Enabling the Gratuitous ARP.**

```
[ipmicfg_HOME] > IPMICFG.exe -garp on
```

Failed to enable Gratuitous ARP, Completion Code=80h



Note: Gratuitous ARP includes Gratuitous ARP requests and replies, updating ARP tables to map MAC addresses and IP addresses. Due to security concerns, it is not supported by default for most network devices. If you want to use this function, please make sure the Gratuitous ARP function is enabled on your network devices.

- **Example 7. Showing the IPv6 mode.**

```
[ipmicfg_HOME] > IPMICFG.exe -ipv6 mode
```

Current IPv6 mode is [Stateless]

Supported IPv6 modes:

0:Stateless

1:Stateful

- **Example 8. Showing IPv6 auto configuration.**

```
[ipmicfg_HOME] > IPMICFG.exe -ipv6 autoconfig
```

Auto Configuration is currently enabled.

- **Example 9. Listing IPv6 static addresses.**

```
[ipmicfg_HOME] > IPMICFG.exe -ipv6 list
```

Maximum number of IPv6 static address: 5

ID	IPv6 Static Address	Prefix
--	-----	-----
0	FE80:0000:0000:0000:0225:90FF:FEEE:59E5	64
1	3333:2222:0000:0000:0000:0000:0000:0000	32
2	Disabled	N/A
3	Disabled	N/A
4	FE80:0000:0000:0000:0225:90FF:FEEE:59E9	64

- **Example 10. Displaying IPv6 static router info.**

```
[ipmicfg_HOME] > IPMICFG.exe -ipv6 route
```

Router 1:

Prefix to Route: 0000:0000:0000:0000:0000:0000:0000:0000/255

Router Address: 0000:0000:0000:0000:0000:0000:0000:0000

Router 2:

Prefix to Route: 0000:0000:0000:0000:0000:0000:0000:0000/255

Router Address: 0000:0000:0000:0000:0000:0000:0000:0000

- **Example 11. Showing IP address protocol.**

```
[ipmicfg_HOME] > IPMICFG.exe -addrptl
```

```
Address Protocol is [ Dual ]
```

```
Address Protocol Types:
```

```
1:IPv4
```

```
2:IPv6
```

```
3:Dual
```

- **Example 12. Setting up an IP address protocol.**

```
[ipmicfg_HOME] > IPMICFG.exe -addrptl 3
```

```
Done.
```

3.2 IPMI Management Functions

Options	Descriptions
-r	Performs a BMC cold reset.
-fd <option>	Resets to the factory defaults without preserving configurations. *To meet various needs, set [option] to 1, 2, or 3. 1: Preserves the configurations in the “Users” section. 2: Restores the factory defaults and the default password of the motherboard. 3: Sets user’s password to ADMIN.
-fdl	Resets IPMI to the factory default. (Clean LAN).
-fde	Resets IPMI to the factory default. (Clean FRU & LAN).
-d	Detects if a BMC reset was successfully performed on the IPMI device. Note that this option can be only used after -r, -fd, -fdl or -fde.
-ver	Gets firmware revision.
-vlan	Gets VLAN status.
-vlan on <VLAN tag>	Enables the VLAN and sets the VLAN tag. If VLAN tag is not given, it uses the previously saved value.
-vlan off	Disables the VLAN.
-selftest	Checks and reports the basic health status of the BMC.
-raw	Sends a RAW IPMI request and prints a response. *Command format: NetFn/LUN Cmd [Data1 ... DataN]
-fan	Gets the fan mode.
-fan <mode>	Sets the fan mode. *Mode parameters, such as 0 or 1, may vary by motherboards. .
-clrint	Clears chassis intrusion.
-reset <index>	Resets system and forces to boot from the selected device. *For the list of index options for a reboot device, please find it in the note below.
-soft <index>	Initiates a soft-shutdown for OS and forces system to boot from the selected device. *For the list of index options for a reboot device, please find it in the note below.
-summary	Displays FW and BIOS information.
-hostname [value]	Gets/Sets a host name.

Options	Descriptions
-mel download <file>	Downloads a BMC maintenance event log to a file.
-mel clear	Clears a BMC maintenance event log.



Notes:

- This is the list of index options for a reboot device.

Index Option	Reboot Device
1	PXE
2	Hard-drive
3	CD/DVD
4	Bios
5	USB KEY
6	USB HDD
7	USB Floppy
8	USB CD/DVD
9	UEFI Hard-drive
10	UEFI CD/DVD
11	UEFI USB KEY
12	UEFI USB HDD
13	UEFI USB CD/DVD
14	UEFI PXE

3.2.1 Examples of Command Executions

The following are selected options from the above table to illustrate their execution.

- **Example 1. Performing a BMC cold reset.**

```
[ipmicfg_HOME] > IPMICFG.exe -r
BMC cold reset successfully completed!
```

- **Example 2. Resetting IPMI to the factory default.**

```
[ipmicfg_HOME] > IPMICFG.exe -fd 2
Reset to the factory default completed.
```

- **Example 3. Getting the firmware revision.**

```
[ipmicfg_HOME] > IPMICFG.exe -ver
Firmware Version: 01.87
```

- **Example 4. Getting the VLAN status.**

```
[ipmicfg_HOME] > IPMICFG.exe -vlan
VLAN is now disabled.
```

- **Example 5. Checking and reporting the basic health status of the BMC.**

```
[ipmicfg_HOME] > IPMICFG.exe -selftest
Selftest: Passed.
```

- **Example 6. Sending a RAW IPMI request and printing a response.**

```
[ipmicfg_HOME] > IPMICFG.exe -raw 6 1
20 01 03 19 02 BF 7C 2A 00 34 06
```

- **Example 7. Getting the fan mode.**

```
[ipmicfg_HOME] > IPMICFG.exe -fan
Current Fan Speed Mode is [ Optimal Mode ]
```

Parameter for setting:

```
0: Standard
1: Full
2: Optimal
```

- **Example 8. Setting the fan mode.**

```
[ipmicfg_HOME] > IPMICFG.exe -fan 0
Done.
```

- **Example 9. Clearing chassis intrusion.**

```
[ipmicfg_HOME] > IPMICFG.exe -clrnt  
Done.
```

- **Example 10. Resetting the system and forcing it to boot from the selected device.**

```
[ipmicfg_HOME] > IPMICFG.exe -reset 0  
Done.
```

- **Example 11. Initiating a soft-shutdown for OS and forcing the system to boot from the selected device.**

```
[ipmicfg_HOME] > IPMICFG.exe -soft 0  
Done.
```

- **Example 12. Displaying FW and BIOS information.**

```
[ipmicfg_HOME] > IPMICFG.exe -summary  
Summary  
-----  
IP                        : 10.136.33.107  
MAC Address              : 00:25:90:EE:58:E7  
Firmware Revision       : 2.18  
Firmware Build Date     : 09/17/2015  
BIOS Version            : 1.0  
BIOS Build Date         : 11/13/2013  
System MAC Address 1    : 00:25:90:E8:70:64  
System MAC Address 2    : 00:25:90:E8:70:65
```

- **Example 13. Setting a host name.**

```
[ipmicfg_HOME] > IPMICFG.exe -hostname dnsserver  
Done.
```

- **Example 14. Downloading a BMC maintenance log to a file.**

```
[ipmicfg_HOME] > IPMICFG.exe -mel download mel.txt  
Downloaded file successfully.
```



Note: The "-mel download" command is not supported when you see the "Prepare download file timeout" message.

3.3 Node Management (NM) 2.0 Functions

Options	Descriptions
-nm nmsdr	Displays NM SDR.
-nm seltime	Gets SEL time.
-nm deviceid	Gets the ID of an ME device.
-nm reset	Reboots ME.
-nm reset2default	Forces ME to reset to default settings.
-nm updatemode	Forces ME to enter the update mode.
-nm selftest	Gets self-test results.
-nm listimagesinfo	Lists ME information of images.
-nm oemgetpower	OEM Power command for ME.
-nm oemgettemp	OEM Temp. command for ME.
-nm pstate	Gets the maximum allowed CPU P-State.
-nm tstate	Gets the maximum allowed CPU T-State.
-nm cpumemtemp	Gets CPU/memory temperature.
-nm hostcpudata	Gets the host CPU data.

3.3.1 Examples of Command Executions

The following are selected options from the above table to illustrate their execution.

- **Example 1. Displaying NM SDR.**

```
[ipmicfg_HOME] > IPMICFG.exe -nm nmsdr  
Record ID           = A7 08  
SDR Version         = 51h  
Record Type         = C0h  
Record Length       = 0Bh  
OEM ID              = 57 01 00 h  
Record Subtype      = 0Dh  
Subtype Version     = 01h  
Salve Address       = 2Ch  
Channel             = 00h  
  
Health Event Sensor Number      = 1Dh  
Exception Event Sensor Number   = 1Eh  
Operational Capabilities Sensor Number = 1Fh  
Alert Threshold Exceeded Sensor Number = 20h
```

- **Example 2. Getting the ID of an ME device.**

```
[ipmicfg_HOME] > IPMICFG.exe -nm deviceid
Device ID           = 50h
Firmware Version    = 2.1.5.95
IPMI Version        = 2.0
Manufacturer ID     = 57 01 00
Product ID Minor Ver = Romley platform
Firmware implemented version = NM Revision 2.0
Image Flag = operational image 1
raw = 50 01 02 15 02 21 57 01 00 02 0b 02 09 50 01
```

- **Example 3. Listing information of ME images.**

```
[ipmicfg_HOME] > IPMICFG.exe -nm listimagesinfo
Recovery Image:
Image Type = Recovery image
raw = 57 01 00 02 01 02 09 55 00
```

- **Example 4. Getting self-test results.**

```
[ipmicfg_HOME] > IPMICFG.exe -nm selftest
PSU Monitoring service error. < 80 03 >
PSU[1] is not responding.
PSU[2] is not responding.
```

- **Example 5. Getting CPU and memory temperature.**

```
[ipmicfg_HOME] > IPMICFG.exe -nm cpumemtemp
CPU#0 = 43(c)
CPU#1 = 44(c)
[CPU#0]CHANNEL#1, DIMM#0(P1_DIMMB1) = 39(c)
[CPU#1]CHANNEL#3, DIMM#0(P2_DIMMH1) = 31(c)
```

- **Example 6. Getting the host CPU data.**

```
[ipmicfg_HOME] > IPMICFG.exe -nm hostcpudata
```

Host CPU data:

End of POST notification was received

Host CPU discovery data provided with that command is valid

Number of P-States = 10

Number of T-States = 15

Number of installed CPUs/socket = 2

Processor Discovery Data-1 = 19 19 18 18 17 17 17 17

Processor Discovery Data-2 = 00 00 00 00 00 00 00 00

3.4 IPMI User & Configuration Management Functions

Options	Descriptions
-pminfo [full]	Displays PMBus health information of power supply.
-psfruinfo	Displays FRU health information of power supply.
-psbbpinfo	Displays status of the backup battery.
-autodischarge <module> <day>	Sets auto discharge by days.
-discharge <module>	Manually discharges a battery.
-user list	Lists user privileges.
-user help	Shows a user privilege code.
-user add <user id> <user name> <password> <privilege>	Adds a user. * For the list of privilege levels, please find it in the note below.
-user del <user id>	Deletes users.
-user level <user id> <privilege>	Updates user privileges.
-user setpwd <user id> <password>	Updates a user password.
-conf download <file>	Downloads IPMI configuration to a binary file.
-conf upload <file> <option>	Uploads IPMI configuration from a binary file. *To bypass a warning message, use the option -p.
-conf tdownload <file>	Downloads IPMI configuration to a text file.
-conf tupload <file> <option>	Uploads IPMI configuration from a text file. *To bypass a warning message, use the option -p.



Note: The list of privilege levels

Level	Privilege
1	Callback
2	User
3	Operator
4	Administrator

3.4.1 Examples of Command Executions

The following are selected options from the above table to illustrate their execution.

- **Example 1. Displaying PMBus health information of the power supply.**

```
[ipmicfg_HOME] > IPMICFG.exe -pminfo
[SlaveAddress = 78h] [Module 1]

Item                               | Value
----                               | ----
Status                             | [STATUS OK] (00h)
AC Input Voltage                    | 121.5 V
AC Input Current                    | 0.56 A
DC 12V Output Voltage               | 12.19 V
DC 12V Output Current               | 3.18 A
Temperature 1                       | 43C/109F
Temperature 2                       | 41C/106F
Fan 1                               | 224 RPM
Fan 2                               | 0 RPM
DC 12V Output Power                 | 42 W
AC Input Power                      | 65 W
PMBus Revision                      | 0x8B22
PWS Serial Number                   | P441PAC17GW2358
PWS Module Number                   | PWS-441P-1H
PWS Revision                        | REV1.0
```


- **Example 2. Displaying FRU health information of the power supply.**

```
[ipmicfg_HOME] > IPMICFG.exe -psfruinfo
[SlaveAddress = 70h] [Module 1]

Item | Value
---- | -----
Status | On
Temperature | 41C/106F
Fan 1 | 229 RPM
Fan 2 | 0 RPM
```

- **Example 3. Displays status of the backup battery.**

```
[ipmicfg_HOME] > IPMICFG.exe -psbbpinfo
[SlaveAddress = 70h] [Module 1]

Item | Value
---- | -----
Manufacturer | SUPERMICRO
Model Name | PWS-206B-1R
Serial Number | TEST1234567890A
Product Version | 1.2
Firmware version | 1.0
----- |
Battery Voltage | 16.27 V
Battery Current | 0 mA
Battery Pack Temp | 30C/86F
Board Temp | N/A
Power Wattage | 200W
Cycle Count | 6
----- |
Battery Power Status | Normal
Remaining Energy | 99%
Discharge Status | None
Discharge Setting | Auto (30 days)
Discharge Remaining Days | 30 days
Battery Status | 0xC0E0
| [FULLY CHARGED]
| [DISCHARGING]
| [TERMINATE CHARGE]
```

- **Example 4. Listing user privileges.**

(In this example, two users are enabled by default, and one user is hidden in the command line.)

```
[ipmicfg_HOME] > IPMCFG.exe -user list
Maximum number of Users: 10
Count of currently enabled Users: 2
User ID | User Name      | Privilege Level | Enable
----- | -
      2 | ADMIN          | Administrator   | Yes
```

- **Example 5. Adding a user.**

```
[ipmicfg_HOME] > IPMCFG.exe -user add 3 ADMINTEST TESTADMIN 4
Done.
```

- **Example 6. Downloading IPMI configuration to a binary file.**

```
[ipmicfg_HOME] > IPMCFG.exe -conf download ipmi.cfg.txt
Downloaded file successfully
```

- **Example 7. Uploads IPMI configuration from a binary file.**

```
[ipmicfg_HOME] > IPMCFG.exe -conf upload ipmi.cfg.txt
This function may reboot the IPMI device.
Do you want to proceed?[y/n]: y
Uploaded file successfully
Please wait for 1 minute to reboot the BMC.
```



Note: The "-conf (t)download" command is not supported when you see the "Prepare download file timeout" message.

The "-conf (t)upload" command is not supported when you see the "Upload file failed, Completion Code=xxh" message.

3.5 IPMI Sensor & System Event Management

Options	Descriptions
-sel info	Shows SEL information.
-sel list	Shows SEL records.
-sel del	Deletes all SEL records.
-sel raw	Shows SEL raw data.
-sdr [full]	Shows SDR records and readings.
-sdr del <sdr id>	Deletes the SDR record.
-sdr ver <v1> <v2>	Gets/Sets the SDR version. (<v1> and <v2> are BCD-format)

3.5.1 Examples of Command Executions

The following are selected options from the above table to illustrate their execution.

- **Example 1. Showing SEL records.**

```
[ipmicfg_HOME] > IPMICFG.exe -sel list
1 | 2012/11/11 15:16:12 | Chassis Intru
  | Assertion:General Chassis intrusion
```

- **Example 2. Showing SEL raw data.**

```
[ipmicfg_HOME] > IPMICFG.exe -sel raw
SEL( 1) 01 00 02 48 00 00 00 20 00 04 05 51 6F F0 FF FF
```

- **Example 3. Showing SDR records and readings.**

```
[ipmicfg_HOME] > IPMICFG.exe -sdr
```

Status	(#)Sensor	Reading	Low Limit	High Limit
-----	-----	-----	-----	-----
OK	(4) CPU1 Temp	44C/111F	0C/32F	86C/187F
OK	(71) CPU2 Temp	44C/111F	0C/32F	86C/187F
OK	(138) System Temp	31C/88F	-5C/23F	80C/176F
OK	(205) Peripheral Temp	44C/111F	-5C/23F	80C/176F
OK	(272) PCH Temp	57C/135F	-5C/23F	90C/194F
OK	(339) FAN1	1800 RPM	600 RPM	18975 RPM
OK	(406) FAN2	1800 RPM	600 RPM	18975 RPM
	(473) FAN3	N/A	N/A	N/A
	(540) FAN4	N/A	N/A	N/A
	(607) FAN5	N/A	N/A	N/A
	(674) FAN6	N/A	N/A	N/A
	(741) FAN7	N/A	N/A	N/A
	(808) FAN8	N/A	N/A	N/A
OK	(875) VTT	1.05 V	0.91 V	1.34 V
OK	(942) CPU1 Vcore	0.89 V	0.54 V	1.48 V
OK	(1009) CPU2 Vcore	0.76 V	0.54 V	1.48 V
OK	(1076) VDIMM ABCD	1.48 V	1.20 V	1.64 V
OK	(1143) VDIMM EFGH	1.50 V	1.20 V	1.64 V
OK	(1210) +1.5 V	1.47 V	1.34 V	1.64 V
OK	(1277) 3.3V	3.31 V	2.92 V	3.64 V
OK	(1344) +3.3VSB	3.31 V	2.92 V	3.64 V
OK	(1411) 5V	5.05 V	4.48 V	5.50 V
OK	(1478) 12V	12.29 V	10.81 V	13.25 V
OK	(1545) VBAT	3.26 V	2.68 V	3.31 V
OK	(1612) HDD Status	0.00	2.68 V	3.31 V
Fail	(1679) Chassis Intru	01 C0 01 00	N/A	N/A
OK	(1746) PS1 Status	01 C0 01 00	N/A	N/A

3.6 FRU Management

Options	Descriptions
-fru info	Shows information of the FRU inventory area.
-fru list	Shows all FRU values.
-fru cthelp	Shows chassis type code.
-fru help	Shows help of FRU Write.
-fru <field>	Shows FRU field value.
-fru <field> <value>	Writes FRU.
-fru backup <file>	Backs up FRU to a file <Binary format>.
-fru restore <file>	Restores FRU from a file <Binary format>.
-fru tbackup <file>	Backs up FRU to a file <Text format>.
-fru trestore <file>	Restores FRU from a file <Text format>.
-fru ver <v1> <v2>	Gets/Sets the FRU version. *<v1> and ,<v2> are BCD-format.)
-fru dmi <\$1> <\$2> <\$3> <\$4> <\$5> <\$6> <\$7> <\$8> <\$9> <\$10> <\$11> <\$12> <\$13> <\$14>	Inputs 14 parameters and writes to FRU Chassis/Board/Product fields. \$1 PRODUCT Manufacturer Name \$2 PRODUCT Product Name \$3 PRODUCT Part Number \$4 PRODUCT Product Version \$5 PRODUCT Serial Number \$6 PRODUCT Asset Tag \$7 BOARD mfg/DateTime \$8 BOARD Board Manufacturer \$9 BOARD Product Name \$10 BOARD Part Number \$11 BOARD Serial Number \$12 CHASSIS Type (HEX value, ex:01,02,03 ...) \$13 CHASSIS Part Number \$14 CHASSIS Serial Number

3.6.1 Examples of Command Executions

The following are selected options from the above table to illustrate their execution.

- **Example 1. Showing information of the FRU inventory area.**

```
[ipmicfg_HOME] > IPMICFG.exe -fru info  
FRU size: 1024 bytes
```

- **Example 2. Showing help of FRU Write.**

```
[ipmicfg_HOME] > IPMICFG.exe -fru help
Available Fields for FRU
Chassis Info Fields:
CT ;Chassis Type
CP ;Chassis Part Number
CS ;Chassis Serial Number
Board Info Fields:
BDT ;Board Mfg. Date/Time (YYYYMMDDhhmm)
BM ;Board Manufacturer
BPN ;Board Product Name
BS ;Board Serial Name
BP ;Board Part Number
Product Info Fields:
PM ;Product Manufacturer
PN ;Product Name
PPM ;Product Part/Model Number
PV ;Product Version
PS ;Product Serial Number
PAT ;Asset Tag
Example:
ipmicfg -fru PS ;read product serial number
ipmicfg -fru PS 123456789 ;write product serial number
```

- **Example 3. Writing FRU.**

```
[ipmicfg_HOME] > IPMICFG.exe -fru BDT 201211121631
Chassis Type (CT) = Unknown(02h)
Chassis Part Number (CP) =
Chassis Serial Number (CS) = 0123456789
Board Mfg. Date/Time(BDT) = 2012/11/12 16:31:00 (DF 5D 87)
Board Manufacturer (BM) = Supermicro
Board Product Name (BPN) = X9DRD-iF
Board Serial Number (BS) = 0123456789
Board Part Number (BP) =
Product Manufacturer (PM) = Supermicro
Product Name (PN) = X9DRD-iF
Product Part/Model Number (PPM) =
Product Version (PV) =
Product Serial Number (PS) = 0123456789
Product Asset Tag (PAT) =
```

- **Example 4. Backing up FRU to a file.**

```
[ipmicfg_HOME] > IPMICFG.exe -fru backup fru.txt
Backed up FRU successfully.
```

- **Example 5. Setting the FRU version.**

```
[ipmicfg_HOME] > IPMICFG.exe -fru ver 1 1
Done.
FRU version is 01.01
```

3.7 Multi Node Management

Options	Descriptions
-tp info	Gets MCU information.
-tp info <type>	Gets information of MCU type. *Type parameters are 1, 2 and 3.
-tp nodeid	Gets a node ID.

3.7.1 Examples of Command Executions

The following are selected options from the above table to illustrate their execution.

- **Example 1: Getting MCU information.**

```
[ipmicfg_HOME] > IPMICFG.exe -tp info
```

Node	Power	IP	Watts	Current	CPU1	CPU2	System
----	-----	-----	-----	-----	----	----	-----
A	Active	10.136.33.31	35W	3.4A	42C	N/A	31C
B	Active	10.136.33.32	27W	2.2A	43C	N/A	31C
C	Active	10.136.33.33	46W	3.8A	45C	N/A	29C
D	Active	10.136.33.34	24W	2.0A	39C	N/A	30C

Node	Node P/N	Node S/N
----	-----	-----
A	X9DRT-P	ZM141S022841
B	X9DRT-P	ZM141S023245
C	X9DRT-P	ZM141S022861
D	X9DRT-P	ZM141S022860

```
Configuration ID      : 4
Current Node ID      : B
System Name          : Test
System P/N           : (Empty)
System S/N           : (Empty)
Chassis P/N          : (Empty)
Chassis S/N          : (Empty)
BackPlane P/N        : (Empty)
BackPlane S/N        : (Empty)
Chassis Location     : 00 00 00 00 00
BP Location          : N/A (FBh)
```

MCU Version : 1.06
BPN Revision : 1.23

- **Example 2. Getting information of MCU type.**

[ipmicfg_HOME] > IPMICFG.exe -tp info 1

Node	Power	IP	Watts	Current	CPU1	CPU2	System
----	-----	-----	-----	-----	----	----	-----
A	Active	10.136.33.31	35W	3.4A	42C	N/A	31C
B	Active	10.136.33.32	27W	2.2A	43C	N/A	31C
C	Active	10.136.33.33	46W	3.8A	45C	N/A	29C
D	Active	10.136.33.34	24W	2.0A	39C	N/A	30C

- **Example 3. Getting a node ID.**

[ipmicfg_HOME] > IPMICFG.exe -tp nodeid

B

3.8 TAS Management

Options	Descriptions
-tas info	Gets TAS information.
-tas pause	Pauses a TAS service.
-tas resume	Resumes a TAS service.
-tas refresh	Triggers TAS to recollect data.
-tas clear	Clears collected TAS data in BMC.
-tas period <sec>	Sets the time length of a TAS update <limit 5 to 60 sec>.
-tas exec <cmd>	Executes a user's specified command.

3.8.1 Examples of Command Executions

The following are selected options from the above table to illustrate their execution.

- **Example 1. Getting TAS information.**

```
[ipmicfg_HOME] > IPMICFG.exe -tas info
```

Item		Value
----		-----
Version		1.1.1
Build Data		150923
Protocol Version		0x01
Status		Running
TAS Start Time		Mon Nov 23 13:39:35 2015
Last Update Time		Thu Dec 10 17:21:00 2015

- **Example 2. Pausing a TAS service.**

```
[ipmicfg_HOME] > IPMICFG.exe -tas pause
```

Done.

- **Example 3. Resuming a TAS service.**

```
[ipmicfg_HOME] > IPMICFG.exe -tas resume
```

Done.

3.9 NVME Management

Options	Descriptions	Requirement of TAS running on management systems
-nvme list	Displays the existing NVME SSD list.	Yes
-nvme info	Displays NVME SSD information.	No
-nvme rescan	Rescans all devices by in-band.	Yes
-nvme insert <aoc> <group> <slot>	Inserts SSD by out-of-band.	No
-nvme locate <HDD name>	Locates SSD. (in-band)	Yes
-nvme locate <aoc> <group> <slot>	Locates SSD. (out-of-band)	No
-nvme stoplocate <HDD name>	Stops locating SSD. (in-band)	Yes
-nvme stoplocate <aoc> <group> <slot>	Stops locating SSD. (out-of-band)	No
-nvme remove <HDD name> [option1] [option2]	Removes NVME device. (in-band) *To disconnect an NVME device on the OS and then eject from BMC, use 0 for [option1]. (By default.) *To disconnect an NVME device on the OS but not eject from BMC afterwards, use 1 for [option1]. *To bypass a warning message, use -p for [option2].	Yes
-nvme remove <aoc> <group> <slot> [option]	Removes NVME device. (out-of-band) *To bypass a warning message, use the option -p.	No
-nvme smartdata [HDD name]	NVME S.M.A.R.T data.	Yes

3.9.1 Examples of Command Executions

The following are selected options from the above table to illustrate their execution.

- **Example 1. Inserting a SSD by out-of-band access.**

```
[ipmicfg_HOME] > IPMICFG.exe -nvme insert 0 0 0  
Done
```

- **Example 2. Removing an NVME device.**

```
[ipmicfg_HOME] > IPMICFG.exe -nvme remove nvme0 -p  
Sending in band remove command...  
Done.  
Waiting for 10 secs to remove device...  
Sending OOB eject command...  
Done.
```

- **Example 3. Displaying the existing NVME SSD list.**

```
[ipmicfg_HOME] > IPMICFG.exe -nvme list
```

Name	Vendor	Capacity	IB Temp.	Locate	Slot
Nvme0	INTEL SSDPE2ME400G4	372.6 GB	25 C	No	0

- **Example 4. Displaying NVME SSD information.**

```
[ipmicfg_HOME] > IPMICFG.exe -nvme info  
[AOC Number: 0] [Firmware Info: 00 00]
```

Item	Value
Slot	0
Located	NO
OOB Temp.	36 C
Class Code	02 08 01
ID	80 86
Serial Number	CVMD44500004400FGN
Model Number	INTEL SSDPE2ME400G4
Port0 Max Link Speed	8.0 GT/s
Port0 Max Link Width	x4
Port1 Max Link Speed	8.0 GT/s
Port1 Max Link Width	x4
Init Power Requirement	25 Watts
Max Power Requirement	25 Watts

3.10 DCMI Management

Options	Descriptions
-dcmi cap	Lists information of DCMI capabilities.
-dcmi power	Gets the DCMI power readings.
-dcmi ctl [value]	Gets/Sets the DCMI management controller ID string.

3.10.1 Examples of Command Executions

The following are selected options from the above table to illustrate their execution.

- **Example 1. Listing info of DCMI capabilities.**

```
[ipmicfg_HOME] > IPMICFG.exe -dcmi cap
Mandatory Platform Capabilities
-----
Temperature Monitor      | Compliant
Chassis Power            | Compliant
SEL Logging              | Compliant
Identification Support   | Compliant

Optional Platform Capabilities
-----
Power Management         | Compliant

Manageability Access Capabilities
-----
VLAN Capable              | Available
SOL Supported              | Available
OOB Primary LAN Channel Available | Available
OOB Secondary LAN Channel Available | Not Present
OOB Serial TMODE Available | Not Present
In-Band KCS Channel Available | Available

SEL Attributes
-----
SEL Automatic Rollover Enabled | Not Present
Number Of SEL Entries          | 0

Identification Attributes
```

```

-----
Asset Tag Support          | Available
DHCP Host Name Support    | Not Present
GUID Support              | Available

```

Temperature Monitoring

```

-----
Baseboard temperature     | At least 1
Processors temperature    | At least 1
Inlet temperature        | At least 1

```

Power Management Device Slave Address

```

-----
7-bit I2C Slave Address Of Device On IPMB | 10h

```

Power Management Controller Channel Number

```

-----
Channel Number           | 00h
Device Revision          | 01h

```

Manageability Access Attributes

```

-----
Mandatory Primary LAN OOB Support (RMCP+ Support Only) | Supported
Optional Secondary LAN OOB Support (RMCP+ Support Only) | Not Supported
Optional Serial OOB TMODE Capability                    | Not Supported

```

• Example 2. Getting the DCMI power readings.

```

[ipmicfg_HOME] > IPMICFG.exe -dcmi power
Instantaneous Power Reading          | 14 Watts
Minimum During Sampling Period       | 6 Watts
Maximum During Sampling Period       | 86 Watts
Average Power Reading Over Sample Period | 15 Watts
IPMI Timestamp                      | 2017/02/24 14:00:22
Sampling Period                     | 172705000 Milliseconds
Power Reading State                  | Activated

```

• Example 3. Getting or setting the DCMI management controller ID string.

```

[ipmicfg_HOME] > IPMICFG.exe -dcmi ctl
(Empty)

```

4 Third Party Software

4.1 IPMI Tool

Please refer to <http://sourceforge.net/projects/ipmitool> for more information.

Contacting Supermicro

Headquarters

Address: Super Micro Computer, Inc.

980 Rock Ave.

San Jose, CA 95131 U.S.A.

Tel: +1 (408) 503-8000

Fax: +1 (408) 503-8008

Email: marketing@supermicro.com (General Information)

support@supermicro.com (Technical Support)

Web Site: www.supermicro.com

Europe

Address: Super Micro Computer B.V.

Het Sterrenbeeld 28, 5215 ML

's-Hertogenbosch, The Netherlands

Tel: +31 (0) 73-6400390

Fax: +31 (0) 73-6416525

Email: sales@supermicro.nl (General Information)

support@supermicro.nl (Technical Support)

rma@supermicro.nl (Customer Support)

Web Site: www.supermicro.com.nl

Asia-Pacific

Address: Super Micro Computer, Inc.

3F, No. 150, Jian 1st Rd.

Zhonghe Dist., New Taipei City 235

Taiwan (R.O.C)

Tel: +886-(2) 8226-3990

Fax: +886-(2) 8226-3992

Email: support@supermicro.com.tw

Web Site: www.supermicro.com.tw